

Slotted turner

Article number: 32Z4034

For use with Merrychef eikon[®] model(s):

e2 e2s e3 e4 e4s e5

Key benefits:



Specifications:

- Stainless steel blade with plastic handle
- Dimensions: 100 mm x 79 mm x 300 mm (4" x 3" x 11.8")

Recommended application:

To turn food over during a cooking profile or to take food out after cooking

Cleaning:

Wipe clean with a soft cloth or sponge in warm soapy water. To avoid damage always follow the recommended cleaning procedure. Do not use hard abrasives or wire wools on accessories.

Suitable for dishwasher cleaning.

Dimensions: